






Tower 5800112
 Tower 5800119
 Tower 5800167
 Tower 5800212
 Tower 5800219
 Tower 5800267
 Tower 5800312
 Tower 5800319
 Tower 5800367

(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimatı

(GB) Assembly instructions




(IT) Istruzioni di montaggio

(PL) Instrukcja montażu

(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу





0
10
20
30
40
50
60
70
80
90
100
110
120
130
140
150
160
170
180
190
200


Service • Assistenza • Dienstverlening • Serwis

Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov • Név • Denumire • Ísim • Название	
Nr. • No. • N° • Номер • Č • Sz	
Typ • Type • Típus • Tipo • Тип	
	







- A



10x40

4x


B



1/4x130

8x


C



1/4x60

8x

D



4,5x60

12x

E



4,0x35

8x

F




4x

G




1x
- H






8x

I







4x





1





2



3



4



5

