


ROMEO TABLE



- (D) Montageanleitung
- (FR) Notice de montage
- (NL) Handleiding voor de montage
- (CZ) Montážní návod
- (HU) Szerelési útmutató
- (TR) Montaj talimatı




- (GB) Assembly instructions
- (IT) Istruzioni di montaggio
- (PL) Instrukcja montażu
- (SK) Návod na montáž
- (RO) Instrucțiuni de montaj
- (RU) ИНСТРУКЦИЯ ПО МОНТАЖУ

Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба


Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название

Nr. • No. • N° • Номер • Č • Sz


Typ • Type • Típus • Tipo •
Тип




1x1




2x1



3x2




M8X20MM
AX16



M6X50MM
BX4





M5
CX1



M6X20MM
DX5

1




M6X50MM
BX4



M5
CX1

2



M8X20MM
AX16



M5
CX1



M6X20MM
DX5

3/4

3

