


LOKE Table



- (D)** Montageanleitung
- (FR)** Notice de montage
- (NL)** Handleiding voor de montage
- (CZ)** Montážní návod
- (HU)** Szerelési útmutató
- (TR)** Montaj talimatı




- (GB)** Assembly instructions
- (IT)** Istruzioni di montaggio
- (PL)** Instrukcja montaży
- (SK)** Návod na montáž
- (RO)** Instrucțiuni de montaj
- (RU)** ИНСТРУКЦИЯ ПО МОНТАЖУ

**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**


Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Ísim • Название

Nr. • No. • N° • Номер • Č • Sz


Typ • Type • Tip • Típus • Типо •
Тип




1x1




2x1



3x1




M10X725MM
Ax4




M10X22MM
Bx4



M10
Cx4



M10
Dx1



EX2



M6x18
Fx2



m6x20
Gx2





4mm
Hx1




IX6

1



M10X725MM
Ax4




EX2



M6x18
Fx2




m6x20
Gx2



4mm
Hx1


2



M10X22MM
BX4



M10
CX4








M10
DX1



Ix6

3



4

