




TIPS

- 1 Please review all parts and hardware before disposing of any packaging.
- 2 Check to be sure that all parts and hardware before you start to assembly.
- 3 Before beginning assembly, separate each type of screw.
- 4 Using a screw that is too long will cause damage.
- 5 Carefully study the screw diagrams below.
- 6 You may receive extra hardware with your unit.
- 7 Place all parts on a clean and smooth surface to avoid the parts from being scratched.
- 8 Keep the product away from heat and humidity.
- 9 Light blue stains and natural wood knots on the product are not considered defects.



PART LIST


<p>A Taller Frame(Outside) 1Pc</p> 	<p>B Taller Frame(Inside) 1Pc</p> 	<p>C Apron(Short)(With Hole) 2Pcs</p> 	<p>D Apron(Short)(Without Hole) 2Pcs</p> 
<p>E Apron(Long) 1Pc</p> 	<p>F Stretcher 1Pc</p> 	<p>G Lower Frame 1Pc</p> 	<p>H Top Panel 1Pc</p> 
<p>I Shelf 3Pcs</p> 	<p>J Table Top 1Pc</p> 	<p>K Bottom Panel 1Pc</p> 	

HARDWARE LIST


<p>L JCBC/W Screw M7 x 60mm 8 Pcs</p> 	<p>M JCBC/W Screw M7 x 40mm 4 Pcs</p> 	<p>N CSK C/B Screw M4 x 32mm 10Pcs</p> 	<p>O Allen key(Ball) M4 1Pc</p> 
--	--	--	--

ASSEMBLY INSTRUCTIONS


1 STEP 1




2 STEP 2



3 STEP 3



4 STEP 4



5 STEP 5

